

TRINITY

FURNITURE INCORPORATED

PO BOX 150 TRINITY, NC 27370 Phone 336-472-6660 Fax 336-475-0037 E-Mail: sales@trinityfurniture.com

EZ 2 Collection

31 Series

To take the cover off

1. Remove seat cushions and back cushions by pulling at the bottom of the back. Pull the bottom of the seat to release velcro, then lift the back to slide it off the dowel located at the top of the chair back
2. Turn chair upside down and remove base caps by removing screws with a Phillips head screwdriver. Remove black bottom by pulling at sew tabs to release the Velcro. At this time you can see three 5/8 inch bolts on the bottom of each arm and one on the inside of back. Remove the back with a 9/16 socket wrench. The arms then will remove from the chair unit. To remove the cover, turn arm upside down and start by pulling on one end of the cover to release Velcro. Repeat around bottom of arm until cover is loose. Remove the cover by sliding to the top of the arm. Repeat on the other arm.
3. Start on the chair unit by removing the outside back using the same method as on the arms. Then remove front seat roll. Remove cover from the back cushion by starting at the bottom and then at the sides. Pull cover off by starting at the bottom and pull to the top of the back. Pull the cover over the top of the back and remove from Velcro. To remove cover from seat cushion, unzip zipper all around back of cushion and remove.

To install the new cover

1. Start with the widest part of the front seat unit at the top and apply the Velcro by starting at one end and working on the other end on top. Pull the cover over the top and attach it to the bottom then to the sides. Attach bottom, then sides. Attach outside back starting with widest part of cover at the top of the back. Apply by starting at the top of the back, start at one end and go to the other end. Pull cover to the bottom of chair. Attach Velcro to both sides. Put the cover on the inside back by sliding cover over the bottom of the rubber to the bottom of the frame and attach to the Velcro. Turn the frame over and attach cover on the inside at the sides.
2. To upholster arms, slide cover over arms and pull cover to bottom of frame by pulling it a little at a time on each end of the arm. When cover is on the arm pull to the bottom and attach on one long side and then the next long side. Attach the short sides next. You can determine the inside of the arm by the feel of the wide, hard strip at the bottom and back of the arm. By using the old cover, find the blowholes with a knife or scissors. Two holes will be at the bottom and one hole will be at the top on the back. Repeat on the other arm.
3. To assemble put inside of the arms to the chair unit. Line up boltholes and install the 9/16-inch bolts. Tighten the bolts. Repeat on the other arm. Turn the chair upside down and attach wooden runners to bottom of arms with the Phillips screws. Attach black bottom by lining up Velcro tabs. Set the chair upright and slide inside back dowel pins into holes on top of chair back, then push bottoms of inside back to the inside of frame to attach. Install seat rubber into the new seat covers and zip up cover.